

SAMSUNG

DIGITAL CAMERA

SAMSUNG NX1

SERVICE Manual

DIGITAL CAMERA



CONTENTS

1. Repair information
2. Product specifications
3. Disassembly and reassembly
4. Troubleshooting
5. PCB diagrams
6. Block diagram
7. Firmware update
8. Adjustment
9. Exploded view and parts list

1. Repair information

- 1-1 Warranty and repair service information 1-1
- 1-2 Precaution for disassembly and reassembly 1-4

2. Product specifications

- 2-1 Specifications 2-1
- 2-2 Product comparison 2-4
- 2-3 Accessories information 2-5
- 2-4 About the memory card 2-8
- 2-5 About the battery 2-9
- 2-6 New Features - Bluetooth 2-10

3. Disassembly and reassembly

- 3-1 Body disassembly - General repair 3-1
- 3-2 Body disassembly - Professional repair 3-20
- 3-3 Body assembly - Professional repair 3-28
- 3-4 Body assembly - General repair 3-36

4. Troubleshooting

- 4-1 SD card related problems 4-1
- 4-2 Power related problems 4-2
- 4-3 LCD related problems 4-2
- 4-4 Error messages 4-3
- 4-5 Top related problems 4-4
- 4-6 EVF related problems 4-5
- 4-7 Shutter related problems 4-5
- 4-8 Button related problems 4-6
- 4-9 Proximity sensor related problems 4-6
- 4-10 Audio playback and recording problems 4-7
- 4-11 Display problems 4-9
- 4-12 External flash problems 4-10
- 4-13 Built-in flash problems 4-10
- 4-14 NFC related problems 4-11
- 4-15 BT/Wi-Fi problems 4-11

5. PCB diagrams

5-1 MAIN PCB	5-1
5-2 STROBO FPCB	5-2
5-3 TOP FPCB	5-2
5-4 BACK KEY PCB	5-2
5-5 DRIVE FPCB	5-3
5-6 HOTSHOE FPCB	5-3
5-7 PROX FPCB	5-3
5-8 VGRIP FPCB	5-4
5-9 POWER KEY FPCB	5-4
5-10 CIS HPCB	5-4
5-11 COMMAND FPCB	5-4

6. Block diagram

7. Firmware update

7-1 Product Initialization.....	7-1
7-2 Body Firmware Update Using User Menu	7-4
7-3 Lens Firmware Update Using User Menu.....	7-6
7-4 Body Firmware Update Using DEV Mode	7-8
7-5 Lens Firmware Update Using DEV Mode	7-12
7-6 Main PCB Recovery	7-16

8. Adjustment

8-1 Adjustment process guide	8-1
8-2 CIS TILT Adjustment	8-2
8-3 CIS DOT DATA & SHUTTER ADJ	8-3
8-4 Entering the CS Mode	8-5
8-5 ISO Adjustment.....	8-7
8-6 AWB Adjustment.....	8-8
8-7 EFS (Electronic First Shutter) Adjustment	8-9
8-8 VFPN & DEFECT Adjustment	8-10
8-9 COLOR SHADING Adjustment.....	8-11
8-10 COUNTRY CODE Setting (Wi-Fi).....	8-12
8-11 SN & Mac ADDR Setting	8-13
8-12 PAF Adjustment.....	8-14
8-13 How to uninstall WI-FI Function.....	8-16

9. Exploded view and parts list

9-1 BODY ASSEMBLY	9-1
9-2 CMOS ASSEMBLY	9-2
9-3 REAR ASSEMBLY	9-3
9-4 VGRIP FPCB ASSEMBLY	9-4
9-5 FRONT CASE ASSEMBLY	9-5
9-6 TOP CASE ASSEMBLY	9-7
9-7 TOP SUB CASE ASSEMBLY	9-8
9-8 TOP LCD ASSEMBLY	9-8

1. Repair information

Guide

We listen carefully to our customers' requirements and always find an optimum solution for their needs. We are committed to your satisfaction and have procedures in place to provide you with a fair, timely and effective means to resolve problems. It combines industry leading preventive assistance with responsive support that helps us address problems quickly and effectively. We will continuously maintain and improve our services to satisfy the needs of our customers.

1-1 Warranty and repair service information

(1) General terms and conditions

It is guaranteed to be free of charge from defects in material and workmanship under normal use for a period of one year from date of purchase.

Digital Camera and lens come with a one year limited warranty from the date of purchase.

*** The duration of the warranty depends on the laws in the country in which it was purchased.**

The following information will be required to process warranty requests:

- a. We imply warranties to one year from the original date of purchase. In the event that the purchaser is unable to provide a warranty card or proof of purchase, the warranty period will be determined by the date of manufacture. The warranty period shall be decreased to three months from the original product manufactured date.
- b. The coverage under this warranty begins on the date of your purchase of the product. In the event that a warranty card or proof of purchase is not available, a purchase receipt, preferably the purchase invoice, to confirm the date of purchase is required for warranty service.
- c. In the event that a valid date of purchase is not available, the warranty period will be determined by the date of manufacture. The warranty period shall be decreased to three months from the original product manufactured date.

(2) Limited Warranty

It reserves the right to retain any parts or components replaced at its discretion in the event of a defect noticed in the product. The period with respect to retaining components may vary respectively depending on its components. We are not liable to repair or replace its faulty product after the Warranty Period has expired.

*** We warrant its retaining camera and lenses for five years and three years for the accessories.**

- a. If a warranty claim is filed after the product has been discontinued, we reserves the right to honor the components warranty. Warranty period may vary depending on the type of components.
- b. In the event that no identical warranty information is available for service repair, company has the right to provide warranty. The warranty does not affect the consumers' rights against the company related to its information.

For the length of the period indicated on the chart below, it starts with the date of original purchase.

(3) Warranty Period for components

Our liability under this warranty shall be limited to the following:

- a. For the product which has been repaired by Samsung or Samsung authorised CSP, the item will be repaired free of charge when the same fault occurs within the warranty period.
Even though the applicable warranty period may have expired, the company will be responsible for the same fault which occurs within two months from the warranty expiration date and the item will be repaired free of charge.
- b. In the event of the component that you have paid the replacement cost is returned under normal use within one year at our premises, such components will be replaced free of charge component of the product which is found to be defective.

<Table. 1-1 Warranty Periods for Parts>

Part Name	Warranty Period
Battery Charger	Six months
AC Adaptor	
Battery	
Remote Control	
CD Software	Three months
Earphone	
Pouch for camera	
Cable	Not applicable

*** The Accessories Warranty period is slightly different from each country, we will follow the policy of each country.**

(4) Repair Claims

1) Repair free of charge

Essentially, the following causes of damage are covered:

- a. Failing to function properly under normal use during the limited warranty period.
- b. Repair Services free of charge is granted for the performance of a specific contract.

2) Repair charges

This warranty does not cover damage caused by:

- a. Defect occurring after the expiration of the Warranty Period.
- b. Damage due to negligence, immersion in water, impact, loss and tampering.
- c. Repair or alteration performed by any party other than Samsung authorized technicians.
- d. Misuse or other improper use of the power button.
- e. Exhausted parts such as batteries, lamps and filters, etc.
- f. Defect that occurs due to sand, dirt liquid, etc. entering the inside of the product casing.
- g. Consumable parts which have ceased working through normal use such as as earphone, battery discharger and various accessories.
- h. Products purchased second hand or any damage that occurs due to a second hand or repair performed by anyone other than Samsung or a Samsung authorized service station.

i. Fire, earthquake, flood or other natural disasters.

The warranty cover period for components is listed below as per table 1-2.

<Table. 1-2 Warranty Period for components>

Types of consumer damages		Compensation		
		Within the warranty period	After the warranty period	
Failing to perform or failing to function properly under normal use	Required for essential repair within 10 days after the purchase	Replace the product or refund	-	
	Required for essential repair within one month after the purchase	Replace the product or repair at free of charge		
	Applicable to repair	Problem occurred twice due to same malfunction	Free of charge	Repair charges
		Problem occurred four times due to some other malfunction		
		Problem occurred three times due to same malfunction	Replace the product or refund	Repair charges
	Problem occurred five times due to some other malfunction			
Not applicable to repair	Within the period with respect to retaining components		Replace the product at the cost of the depreciated value or refund its price added 5% of depreciation	
Failing to perform or failing to function properly as a result of willful intent and negligence of customer	Applicable repair	Repair charges	Repair charges	
	Not applicable to repair (Except for defects or malfunction as a result of fire or flood or other natural disasters)	Replacement charge	Repair charge and replace the product at the cost of the depreciated value	


*** The Warranty period is slightly different from each country, we will follow the policy of each country.**

1-2 Precaution for disassembly and reassembly

CAUTION

1. Use the anti-static handling procedures included with the anti-static mat to ensure that there is no electrostatic discharge and component damage.
2. Static electricity is the biggest danger to the PCB parts you are about to disassemble or assemble. It's important to use your anti-static wrist strap to prevent damage to these components.
3. Dismantling a discrete electronic component such as main capacitor is dangerous. The capacitor contains high voltage, which can cause a severe electric shock if you touch it. This holds a charge even when the unit is not plugged in and is capable of delivering a fatal shock.
4. Using excessive force during disassembly and assembly can damage locking parts. Use care when handling "Locking parts" to avoid damage to FPCB or wire. Apply pressure only at the points designated in the maintenance instructions.
5. Due to increasing environmental concerns, a number of restrictions have been placed on the material content of electronic components and electronic assemblies. It requires utilizing Lead-Free (Pb-free) Soldering.
6. The following precautions must be observed when handling such components below.

<Table. 1-3 Precaution for disassembly and reassembly>

Component	Precautions
FPCB	<p>- FPCB is brittle material. It can be easily damaged thus it should be handled with care. It is recommended to use wooden or plastic tweezers for manual placement.</p> <p>- If you look closely at the insertion part on FPCB, color is divided into dark brown and light brown. You must be inserted into inside on connector the all part on dark brown on FPCB. So it's the only light brown on FPCB out of connector should be visible to eye. When the assembly is finished, the connector is must be assembled as ② on shown below.</p> 
CCD (CMOS) IR CUT Filter LCD, LENS	<p>Be careful not to stained your finger. It is recommended to use wooden or plastic tweezers for manual placement. Stain is often caused by the Alcohol used in these components. Find a clean, well-ventilated place to do your work.</p>
PCB	<p>Use an anti-static mat as well as an anti-static wrist strap to avoid ESD damage to PCB.</p>
CONNECTOR	<p>The use wooden or plastic tweezers is recommended for manual placement. Metal tip tweezer might make marks or damage.</p>
BARREL	<p>Always follow proper direction while assembling the components of the barrel.</p>

2. Product specifications

2-1 Specifications

<Table. 2-1 Specifications>

Image Sensor	
Sensor size/Type	23.5 X 15.7 mm / BSI CMOS
Eective pixels/Total pixels	Approx. 28.2M mega-pixels / Approx. 30.7M mega-pixels
Color filter	RGB primary color filter
Lens Mount	
Type	Samsung NX Mount
Available lens	Samsung lenses (3D lens supported)
Image Stabilization	
Type	Lens shift (depends on lens)
Mode	Off, Mode 1, Mode 2
Distortion Correct	
Off/On (depends on lens)	
i-Function	
Aperture, Shutter Speed, EV, ISO, White Balance, intelli-Zoom	
Dust Reduction	
Type	Super sonic drive
Display	
Type	Super AMOLED with Touch Screen
Size	3.0" (Approx. 76.6 mm)
Resolution	1036 k dots
Field of view	Approx.100 %
Angle	Tiltable (Up 90°, Down 45°)
Viewnder	
Type	Electronical viewfinder (OLED) (Eye Contact Sensor)
Resolution	XGA 2360 k dots
Eyepoint	Approx. 21.0 mm
Diopter adjustment	Approx. -4.0~+2.0 m ⁻¹
Field of view	Approx. 100 %
Magnification	Approx. 1.04 X (APS-C, 50 mm, -1 m ⁻¹)
Focusing	
Type	Hybrid AF
Focusing point	<ul style="list-style-type: none"> • Total AF point: 205 points (Phase Detection AF), 209 points (Contrast AF) • AF Range: EV -4~20
Mode	Active AF, Single AF, Continuous AF, Manual Focus
AF Assist Lamp	Yes
Shutter	
Speed	<ul style="list-style-type: none"> • Auto: 1/8,000 sec.-1/4 sec. • Manual: 1/8,000 sec.-30 sec. • Bulb

Exposure	
Metering system	TTL 221 (17X13) Block segment
	Metering: Multi, Center-weighted, Spot
Compensation	Still: ±5 EV, Movie: ±3 EV (1/3 EV Step)
ISO equivalent	Auto, 100–25600 (1 EV or 1/3 EV Step) * You can expand up to ISO 51200.
Drive Mode	
Mode	Single, Continuous, Timer, Bracket
Continuous shooting	Continuous shooting
Bracket shooting	Auto exposure bracketing (±3 EV), White Balance bracketing, Picture Wizard bracketing, Depth bracketing
Self-timer	2–30 sec. (1 second interval)
Flash	
Type	Built-in flash
Mode	Smart Flash, Auto, Auto Red-eye, Fill in, Fill-in Red, 1st Curtain, 2nd Curtain, Off, Auto FP Sync (available only with supported external flashes)
Guide number	11 (based on ISO 100)
Angle of view	28 mm (35 mm film equivalent)
Sync speed	Less than 1/250 sec.
Flash EV	-2–+2 EV (1/2 EV Step), FEL
External flash	Optional Samsung external flashes
Sync terminal	Hot-shoe
Dynamic Range Expansion	
Off/Smart Range+/HDR	
White Balance	
Mode	Auto WB, Daylight, Cloudy, Fluorescent White, Fluorescent NW, Fluorescent Daylight, Tungsten, Tungsten (Auto), Flash WB, Custom Set, Color Temperature (Manual)
Micro adjustment	Amber/Blue/Green/Magenta 7 steps respectively
Effect	
Picture wizard	Standard, Vivid, Portrait, Landscape, Forest, Retro, Cool, Calm, Classic, Custom1, Custom2, Custom3, Custom4
Smart filter	Vignetting, Miniature (H), Miniature (V), Watercolor, Selective Color (R/G/B/Y 4 Colors)
Picture Wizard	
Mode	Standard, Vivid, Portrait, Landscape, Forest, Retro, Cool, Calm, Classic, Custom1, Custom2, Custom3
Parameter	Color (Red, Green, Blue), Saturation, Sharpness, Contrast, Hue
Still	
Mode	Auto, Program, Aperture Priority, Shutter Priority, Manual, Custom1, Custom2, Smart
Smart mode	Beauty Face, Landscape, Action Freeze, Rich Tones, Panorama, Waterfall, Silhouette, Sunset, Night, Fireworks, Light Trace, Multi Exposure, Samsung Auto Shot
Quality	Super Fine, Fine, Normal
Color space	sRGB, Adobe RGB
Video	
Type	MP4 (HEVC), AVI (MJPEG)
Format	Movie: HEVC (H.265), MJPEG (VGA 30 fps only), Sound: AAC
Movie AE mode	Auto, Program, Aperture Priority, Shutter Priority, Manual, Custom1, Custom2, Smart
Frame rate	<ul style="list-style-type: none"> • NTSC: 60 fps, 30 fps, 24 fps • PAL: 50 fps, 25 fps, 24 fps

Fast / Slow Movie	x0.25 (1920X1080 30 fps/25 fps, 1280X720 30 fps/25 fps, 640X480 30 fps/25 fps only), x0.5 (1920X1080 60 fps/50 fps/30 fps/25 fps, 1280X720 60 fps/50 fps/30 fps/25 fps, 640X480 60 fps/50 fps/30 fps/25 fps only), x5, x10, x20
Quality	HQ, Normal, Pro (4096X2160, 3840X2160 only)
Sound	Stereo
Playback	
Type	Single image, Thumbnails (15/24), Slide show, Movie
Edit	
Still	Auto Adjustment, Brightness, Color Temperature, Contrast, Crop, Exposure, Face Retouch, Hue, Resize, RGB Adjustment, Rotate, Saturation, Smart Filter
Movie	Still image capture, Time trimming
Memory	
External media	SD card, SDHC card, SDXC card (up to 64 GB guaranteed), UHS-I, UHS-II supported
Network and Wireless Connectivity	
Wi-Fi	IEEE 802.11b/g/n/ac
NFC	Yes
Connectivity support	Bluetooth
Interface	
Digital output connector	USB 3.0
Video output	HDMI (NTSC, PAL)
External release	Yes
USB	Yes
Audio	3.5 mm stereo MIC input, 3.5 mm stereo output
Battery	
Capacity	1,860 mAh
Charging	DC 5.0 V, 2 A via Micro USB port
Still image capturing time	500 shots (CIPA Standard)
Physical Specification	
Dimensions (W X H X D)	138.5 X 102.3 X 65.8 mm
Weight	Approx. 550g (body only)
Operating Environment	
Operating Temperature	0–40 °C
Operating Humidity	5–85 %
Software	
i-Launcher (web version included), Adobe Photoshop Lightroom, Samsung DNG Converter, Samsung Movie Converter, Power Media Player	
System Requirement	
Windows	Windows 7/8/8.1, Intel 3rd Gen. i5 3.4 GHz or higher (equivalent AMD processor)
Macintosh	Mac OS 10.7 or higher

2-2 Product comparison

<Table. 2-2 Product comparison>

Specs	Model	EV-NX1	EV-NX30
Image			
Image Sensor(size)		BSI CMOS(13.2 X 8.8 mm)	CMOS(23.5 X 15.7mm)
Eective pixels		Approx. 28.2 mega-pixels	Approx. 20.3 mega-pixels
Total pixels		Approx. 30.7 mega-pixels	Approx. 21.6 mega-pixels
Weight		550 g (without battery and memory card)	368 g (without battery and memory card)
Dimensions (W X H X D)		138.5 X 102.3 X 65.8 mm (without protrusions)	127 X 95.5 X 43.25 mm (without protrusions)
Lens Mount		Samsung NX Mount	Samsung NX Mount
Available lens		Samsung lenses (3D lens supported)	Samsung lenses
Display		<ul style="list-style-type: none"> Type : Super AMOLED with Touch Screen Size : 3.0" (Approx. 76.6 mm) Angle : Tilttable (Up 90°, Down 45°) 	<ul style="list-style-type: none"> Type : Super AMOLED Touch Panel Size : 3.0" (Approx. 76.7 mm) Angle : Swivel (Horizontal 180°, Vertical 270°)
i-Function		Aperture, Shutter Speed, EV, ISO, White Balance, intelli-Zoom	①Depth, ②Zoom(X1.2, 1.4, 1.7, 2.0), ③Contrast
Shutter		<ul style="list-style-type: none"> Type : Electronically controlled vertical-run focal plane shutter Speed : - Auto: 1/8,000 sec -1/4 sec. - Manual: 1/8,000 sec - 30 sec. - Bulb 	<ul style="list-style-type: none"> Type : Electronically controlled vertical-run focal plane shutter Speed : - Auto: 1/8,000–1/4 sec. - Manual: 1/8,000–30 sec. - Bulb (time limit: 4 min)
ISO		Auto, 100–25600 (1 EV or 1/3 EV Step)	<ul style="list-style-type: none"> 1 Step: Auto, ISO 100, ISO 200, ISO 400, ISO 800, ISO 1600, ISO 3200, ISO 6400, ISO 12800, ISO 25600 1/3 Step: Auto, ISO 100, ISO 125, ISO 160, ISO 200, ISO 250, ISO 320, ISO 400, ISO 500, ISO 640, ISO 800, ISO 1000, ISO 1250, ISO 1600, ISO 2000, ISO 2500, ISO 3200, ISO 4000, ISO 5000, ISO 6400, ISO 8000, ISO 10000, ISO 12800, ISO 16000, ISO 20000, ISO 25600 * Auto ISO settings are selectable up to ISO 3200.
Flash		<ul style="list-style-type: none"> Built-in flash : A-TTL popup flash External flash : Optional Samsung external flashes 	<ul style="list-style-type: none"> Built-in flash : A-TTL popup flash External flash : Optional Samsung external flashes
Network and Wireless Connectivity		<ul style="list-style-type: none"> Wi-Fi : IEEE 802.11b/g/n/ac, Bluetooth 3.0 NFC : Yes Connectivity support : Bluetooth 	<ul style="list-style-type: none"> Wi-Fi : IEEE 802.11b/g/n support Dual Band NFC : Yes
Storage		External memory (optional): SD card (2 GB guaranteed), SDHC card (up to 32 GB guaranteed), SDXC card (up to 64 GB guaranteed, UHS-I, UHS-II supported)	External memory (optional): SD card (2 GB guaranteed), SDHC card (up to 32 GB guaranteed), SDXC card (up to 64 GB guaranteed), UHS-1 card - Class 6 and above recommended
		Built-in Memory : No	Built-in Memory : No
Distortion Correct		<ul style="list-style-type: none"> Type : Lens shift (depends on lens) Mode : Off/Mode 1/Mode 2 	<ul style="list-style-type: none"> Type : Lens shift (depends on lens) Mode : Off/Mode 1/Mode 2
DC power input		DC 5.0 V, 2 A micro USB, USB 3.0	DC 5.0 V, 1 A micro USB, USB 2.0
		USB Charge :Yes	USB Charge : Yes
Power Source		BP1900(1860 mAh, 7.2 V)	BP1410(1410 mAh, 7.6 V)

2-3 Accessories information

<Table. 2-3 Packing items information>

	Image	Description	Part No.	
Accessories		Camera(NX1) (including the body cap and hot-shoe cover)	EV-NX1	
		Adapter (ETA0U80KBK)	EP-TA12EBE_EU	GH44-02783A
			EP-TA12JBE_USA	GH44-02788A
			EP-TA12UBE_UK	GH44-02779A
			EP-TA12UBE_UAE(UK)	GH44-02791A
			EP-TA12HBE_AUS	GH44-02781A
			EP-TA12JBS_MEX	GH44-02786A
			EP-TA12SBE_IL	GH44-02784A
			EP-TA12BBB_BRA	GH44-02806A
			EP-TA12CBC_CN	GH44-02782A
			EP-TA12IBE_IND	GH44-02805A
	EP-TA12RBS_ARG	GH44-02785A		
	USB 2.0 Cable  	EA-CB5MU10E	AD39-00194A	
	Battery Charger	CHARGER_CN/TW	AD44-00261A	
	Rechargeable Battery	NX BATTERY(BP1900)_CN	AD43-00254A	
		NX BATTERY(BP1900)_TW	AD43-00255A	
		NX BATTERY(BP1900)_UAE	AD43-00256A	
	Software CD-ROM (User manual included)		AD46-00450A	
	Adobe Photoshop Lightroom DVD-ROM		Service does not apply	
	Strap		AD63-08062A	

	Image	Description			
Accessories		Quick Start Guide			
		Country	Part No.	Country	Part No.
		NX1_QSG_S.CHI	AD68-08594A	NX1_QSG_SLO	-
		NX1_QSG_ENG	AD68-08595A	NX1_QSG_SLV	-
		NX1_QSG_GER	AD68-08596A	NX1_QSG_TUR	AD68-08605A
		NX1_QSG_FRA	AD68-08597A	NX1_QSG_UKR	-
		NX1_QSG_SPA	-	NX1_QSG_POL	-
		NX1_QSG_DUT	AD68-08598A	NX1_QSG_RUM	-
		NX1_QSG_ITA	AD68-08599A	NX1_QSG_ENG(SEA)	AD68-08607A
		NX1_QSG_RUS	-	NX1_QSG_SPA(SEA)	AD68-08608A
		NX1_QSG_SWE	AD68-08600A	NX1_QSG_LAV	-
		NX1_QSG_DAN	AD68-08601A	NX1_QSG_LIT	-
		NX1_QSG_BUL	-	NX1_QSG_T.CHI	AD68-08606A
		NX1_QSG_CZE	-	NX1_QSG_GRE	-
		NX1_QSG_ARA	AD68-08602A	NX1_QSG_SER	-
		NX1_QSG_FIN	AD68-08603A	NX1_QSG_CRO	-
		NX1_QSG_HUN	-	NX1_QSG_VIT	-
		NX1_QSG_PER	-	NX1_QSG_POR_BR(BR,PY)	-
		NX1_QSG_NOR	AD68-08604A	NX1_QSG_THA	-
		NX1_QSG_POR(PT)	-	NX1_QSG_HEB	-

	Image	Description	Model name	Note
Optional accessories		Rechargeable Battery	ED-BP1900	
		Battery Charger	ED-CHARGER_CN/TW	AD44-00261A
		Remote Switch	ED-SR2NX02	
		Flash	ED-SEF580A	
			ED-SEF220A	
		K Mount Adapter	ED-MA9NXK/KR	
		Protector	ED-LF405PT/KR	Compatibility lens(2050)
			ED-LF43PT/KR	Compatibility lens(30, 45, 16, 20)
			ED-LF52PT/KR	Compatibility lens(60, 50200)
			ED-LF58PT/KR	Compatibility lens(1855, 1224)
			ED-LF67PT/KR	Compatibility lens(18200, 85)
		ND Filter	ED-LF405ND4/KR	Compatibility lens(2050)
			ED-LF43ND4/KR	Compatibility lens(30, 45, 16, 20)
			ED-LF52ND4/KR	Compatibility lens(60, 50200)
			ED-LF58ND4/KR	Compatibility lens(1855, 1224)
	CPL Filter	ED-LF43PL/KR	Compatibility lens(30, 45, 16, 20)	
		ED-LF52PL/KR	Compatibility lens(60, 50200)	
		ED-LF58PL/KR	Compatibility lens(1855, 1224)	
	USB 2.0 Cable	EA-CB5MU05E		
	HDMI Cable(A to D Type)	EA-CBHD10D		
	Vertical Grip	ED-VGNX01		

2-4 About the memory card

The memory capacity may differ depending on shooting scenes or shooting conditions. These capacities are based on a 4 GB SD card.

<Table. 2-5 Memory card capacity>

Size		Quality						
		Super Fine	Fine	Normal	RAW	RAW+ S.Fine	RAW+ Fine	RAW+ Normal
Photo	28M (6480X4320)	256	471	809	84	63	71	76
	13.9M (4560X3040)	475	815	1,270	-	73	79	81
	7.1M (3264X2176)	801	1,253	1,744	-	80	83	84
	3M (2112X1408)	1,379	1,863	2,259	-	84	86	86
	23.6M (6480X3648)	299	542	911	-	66	73	77
	11.9M (4608X2592)	537	905	1,376	-	75	80	82
	6.2M (3328X1872)	879	1,346	1,832	-	81	83	85
	2.4M (2048X1152)	1,545	2,008	2,363	-	85	86	87
	18.7M (4320X4320)	368	653	1,064	-	70	76	79
	9.5M (3088X3088)	642	1,050	1,537	-	77	81	83
	4.7M (2160X2160)	1,064	1,553	2,015	-	82	84	86
	2M (1408X1408)	1,668	2,109	2,431	-	85	86	87

Size		Quality		
		HQ	Normal	
Video	 DC 24P	4096X2160 (24fps)	Appox. 07' 15"	Appox. 09' 04"
	 UHD 30P	3840X2160 (30fps)	Appox. 06' 31"	Appox. 08' 09"
	 FHD 60P	1920X1080 (60fps)	Appox. 15' 09"	Appox. 18' 58"
	 FHD 30P	1920X1080 (30fps)	Appox. 26' 14"	Appox. 32' 52"
	 FHD 24P	1920X1080 (24fps)	Appox. 29' 53"	Appox. 37' 27"
	 FHD 15P*	1920X1080 (15fps)	Appox. 35' 44"	Appox. 44' 38"
	 HD 60P	1280X720 (60fps)	Appox. 32' 18"	Appox. 40' 29"
	 HD 30P	1280X720 (30fps)	Appox. 55' 19"	Appox. 69' 26"
	 VGA 60P	640X480 (60fps)	Appox. 91' 30"	Appox. 113' 29"
	 VGA 30P	640X480 (30fps)	Appox. 150' 35"	Appox. 190' 19"
	 MJPEG	640X480 (MJPEG)	Appox. 18' 54"	Appox. 23' 34"

*  is available only with some Smart Filter options.

- The figures above are measured without using the zoom function.
- Available recording time may vary if you use the zoom.
- Several videos were recorded in succession to determine the total recording time.
- The maximum recording time is 29 minutes and 59 seconds per file.

2-5 About the battery

<Table. 2-6 Battery specifications>

Item	Description
Model	BP1900
Type	Lithium-ion battery
Cell capacity	1,860 mAh
Voltage	7.2 V
Charging time* (When the battery is completely discharged)	Approx. 170 min. (Approx. 340 min. when the vertical grip is connected)

* The figures above are based on when you use the provided USB cable and AC adaptor.
Charging the battery by connecting it to a computer may take longer.

<Table. 2-7 Battery life>


Shooting mode	Average time / Number of photos
Photos	Approx. 250 min./Approx. 500 photos
Videos	Approx. 110 min. (Record videos at 3840X2160 resolution and 30 fps.)

- The figures above are based on the CIPA test standards. Your results may differ depending on your actual usage.
- Available shooting time differs depending on background, shooting interval, and use conditions.
- Several videos were recorded in succession to determine the total recording time.

2-6 New Features - Bluetooth

This feature allows you to exchange files with other devices.

Set to connect your camera to a smart phone automatically via the Bluetooth feature. If the devices have previously been connected and you launch Samsung Camera Manager on the smart phone, they will connect via Bluetooth automatically.



3. Disassembly and reassembly

3-1 Body disassembly - General repair

1



SCREW-MACHINE:1.4X5.0

Remove two screws.


2



SCREW-MACHINE:1.4X5.0

Remove one screw.

3




Open the VGRIP cover and remove three screws.

4



Slide the EYE PIECE ASSY and lift it up in the direction of the arrow as in the picture above.

5



Remove five screws.

6



Separate the KNOB EVF ASSY and the EVF COVER ASSY.

7



Separate the LOCK, and slowly lift up the BACK COVER. LCD FPCB and KEY FPCB are connected each other inside of the body.



Open the BATTERY COVER, and separate the LOCK using the REMOVE TOOL as in the picture above.



CAUTION


Be very careful when you take apart the connector in step 8 and 10. FPCB can be easily damaged.

8





Remove two connectors.

9




Remove the FRONT CASE ASSY.

10




Remove one connector.


11



Remove eleven screws.




Remove the WHEEL KEY ASSY and the EVF BUTTON FPCB ASSY.




Remove the components in numerical order as it shown in the picture above.

14



Take two screws apart and remove the sponge tape.

15



Remove the OLED BASE ASSY.



CAUTION

Be very careful when you take apart the connector in step 16. FPCB can be easily damaged.

16

① Open the connector, and remove FPCB.

② Pull FPCB to take it apart.

③ Pull the connector to take it apart.

④ Pull the socket to take it apart.

⑤ SCREW-MACHINE (PH,+ ,B,M1.4,L4.0SL)

Remove eleven connectors and sockets. Remove six screws.

17

MAIN PCB

Remove the MAIN PCB.

18



SCREW-MACHINE:PH,+B,M1.4,L4.0SL

Remove one screw.

19



SCREW TAP 1.4X3.5

Remove one screw.

20




SCREW-MACHINE:1.4X5.0

Open the flash, and remove one screw under the flash.


21

SCREW MACHINE;
PH,+ ,M1.4,L3.0 BK



Remove two screws.

22



Remove the TOP ASSY in the direction of the arrow as in the picture above.
- Be very careful. There is a connector attached to the TOP ASSY.

**CAUTION**


There is a risk of electric shock when you remove the component of TOP ASSY. Please refer to step 23 for discharging electricity.

23




Touch a discharger to the marked area to discharge electricity.

24




Pull the connector in the direction of the arrow to take it apart as it shown in the picture above.

25




Remove the TOP ASSY.

26




Remove three screws.

27




Lift up the EVF ASSY and remove it.

28




Slide the HOLDER POP UP ASSY in the direction of the arrow to take it apart as it shown in the picture above.

29




Remove one connector and four screws.

30




Remove five screws.

31




Remove the components in numerical order as it shown in the picture above.

32




Remove two connectors and four screws.

33



Remove the components in numerical order as it shown in the picture above.

34




Remove the components in numerical order as it shown in the picture above.

35




Remove the HOT SHOE-PMO COVER and the IPR-PLATE SPRING SHOE.

36




Remove two screws.

37



Remove HOLDER-HANGER L.


38



Remove three screws.

39


SCREW-MACHINE
;CH,M1.4,L3,NI



Remove three screws.

40

① HDMI COVER ASSY




② HOLDER TRIPOD

Remove the HDMI COVER ASSY and the HOLDER TRIPOD.

3-2 Body disassembly - Professional repair

1

SCREW-MACHINE
;FH,+,M1.7,L4.0,NI




Remove three screws.

2


② SPRING CMOS ADJUST

① CMOS-ASSY




Remove the CMOS-ASSY and three SPRING CMOS ADJUSTS.

3




Remove the CIS FPCB.

4




Remove two screws.

5



Remove the SHUTTER ASSY.

6



Remove four screws.



CAUTION


Be careful not to lose PIN when you follow step 7.

7



Remove the components in numerical order as it shown in the picture above.

8




Remove four screws.

9



Remove the components in numerical order as it shown in the picture above.
- When you remove the HOLDER-MOUNT, first remove the adhesive of the speaker.

10




Remove three screws.

11




Remove the GRIP REAR.

12




Remove two screws.

13




Remove the CHAMBER BODY ASSY and COVER SD ASSY.

14



Remove three locks.


15



Remove the components in numerical order as it shown in the picture above.


3-3 Body assembly - Professional repair

1




Put the components together in numerical order as it shown in the picture above.

2



Make sure three locks are assembled properly.

3



Put the components together in numerical order as it shown in the picture above.

4




Tighten two screws.

5




Attach the GRIP REAR.

6




Tighten three screws.

7



Put the components together in numerical order as it shown in the picture above.
 - Check the assembly appearance of the Speaker & FPCB & wire of HOLDER INNER MOUNT-ASSY.


8



Tighten four screws.




Put the components together in numerical order as it shown in the picture above.
- Align the holes when you put the ICT DECO MOUNT and the PLATE-MOUNT LENS together.




Tighten four screws.

11




Attach the SHUTTER ASSY.

12



Tighten two screws.


13



Attach the CIS FPCB.

14


① SPRING CMOS ADJUST



Attach the CMOS-ASSY and three SPRING CMOS ADJUSTS.


15

SCREW-MACHINE
;FH,+M1.7,L4.0,NI




Tighten three screws.

3-4 Body assembly - General repair




Attach the HDMI COVER ASSY and the HOLDER TRIPOD.




Tighten three screws.

3




Tighten three screws.

4




Attach the HOLDER-HANGER L.

5




Tighten three screws.

6




Put the components together in numerical order as it shown in the picture above.

7




Put the components together in numerical order as it shown in the picture above.

8




Tighten four screws and attach two connectors.

9




Put the components together in numerical order as it shown in the picture above.

10



Tighten five screws.

11




Tighten four screws and attach one connector.

12




Slide the IPR-PLATE SPRING SHOE in the direction of the arrow as in the picture above. Attach the HOT SHOE-PMO COVER.

13




Slide the HOLDER POP UP ASSY in the direction of the arrow as in the picture above.

14




Attach the EVF ASSY.

15




Tighten three screws.

16



Attach the TOP ASSY and two connectors.

- Make sure that FPCB or the wires are not stuck between covers when you attach the TOP ASSY.



Tighten two screws.



Tighten one screw.



Tighten one screw.


20




SCREW-MACHINE: 1.4X5.0

Open the flash, and tighten one screw under the flash.


21



Attach the MAIN PCB.
 – Pull all FPCB out over the MAIN PCB.




Tighten six screws and attach eleven connectors and sockets.




Attach the OLED BASE ASSY.

24




Tighten two screws and attach the WP FRONT SPONGE TAPE.

25




Put the components together in numerical order as it shown in the picture above.

26




Attach the WHELL KEY ASSY and the EVF BUTTON FPCB ASSY.

27




Tighten eleven screws and attach FPCB.


28



Attach the connector.



Connect FPCB to the connector.



Attach two connectors.

29



Attach the FRONT CASE ASSY.

30




Attach the EVF COVE ASSY and the KNOB EVF ASSY.

31



Tighten five screws.

32



Slide the EYE PIECE ASSY in the direction of the arrow as in the picture above.

33




Tighten two screws.

34



Tighten one screw.


35



Tighten three screws and attach the VGRIP COVER.

4. Troubleshooting

4-1 SD card related problems

Problem		
There is no sound from the camera.		
Solution	Images for reference	
<p>1</p> <ul style="list-style-type: none"> - Check the pins on your SD card. Make sure there is no dirt on the contacts. - Check if the SD card is damaged. 		
<p>2</p> <ul style="list-style-type: none"> - Check the SMD of the SD card socket on Main PCB. - Check the detect pins of your SD card. 		

4-2 Power related problems


Problem

Power does not turn on.

Solution

- ① Check the connection of the connector between MAIN PCB and TOP PCB.
- ② Check the connection of LCD FPCB.
(It can be a display problem.)

Images for reference



4-3 LCD related problems


Problem

Touchscreen is not responding.

Solution

Check the connection of LCD FPCB.

Images for reference



4-4 Error messages


Problem

“Error01” appears on the screen.

Solution

Check the connection of the SHUTTER WIRE HARNESS on MAIN PCB.

Images for reference




Problem

“There is no lens.” appears on the screen. (The camera does not recognize the lens.)

Solution

Check the connection of the LENS DETECT WIRE HARNESS.

Images for reference



4-5 Top related problems


Problem

Power, Mode dial, display indicator and assist illuminator no longer work.

Solution

Check the connection between MAIN PCB and TOP FPCB..

Images for reference




Problem

Check the connection between MAIN PCB and TOP FPCB.

Solution

Check the connection between Main PCB and DRIVE FPCB.

Images for reference



4-6 EVF related problems


Problem

EVF is not working. / MAIN LCD screen is working, but the EVF screen is not displayed.

Solution

Check the connection between MAIN PCB and EVF FPCB.

Images for reference



4-7 Shutter related problems


Problem

When I turn on the camera, the shutter is malfunctioning itself.

Solution

Check the connection of SHUTTER FPCB on MAIN PCB.

Images for reference



4-8 Button related problems


Problem

Buttons on the back of the camera.
(Menu, Fn, Record, Playback, Delete and 5-way controller button) no longer work.

Solution

Check the connection of BACK KEY FPCB.

Images for reference



4-9 Proximity sensor related problems


Problem

Proximity sensor is not working.

Solution

Check the connection of proximity sensor FPCB.

Images for reference



4-10 Audio playback and recording problems



Problem

There is no sound from the speaker.

Solution

- ① Check the soldering points and see if they are damaged.
(Make sure the wires are not damaged and attached to the right positions.)
- ② Check the connection between MAIN PCB and STROBO FPCB. (You should remove the front cover.)

Images for reference





Problem

The speaker works, but the audio is not recording.

Solution

Check the soldering points of the built-in microphone at the TOP ASSY, and see if FPCB is damaged. Make sure the wires are soldered to the right positions.)

Images for reference




Problem

External microphone and earphone no longer work.

Solution

- ① Make sure that all soldering points of the earphone jack are properly connected to the board.
- ② Make sure that all soldering points of the microphone jack are properly connected to the board.

Images for reference



4-11 Display problems



Problem

There is horizontal or vertical noise in images. / The LCD monitor does not display clear images. / The image on the display is distorted. / LCD monitor is blank.

Solution

- ① Check the connection of LCD FPCB.
- ② Check the connection of CIS FPCB.

Images for reference



4-12 External flash problems


Problem

The flash does not fire.

Solution

- ① Check the connection between MAIN PCB and drive FPCB.
- ② Check the soldering points of the HOTSHOE at TOP.

Images for reference



4-13 Built-in flash problems


Problem

The flash does not fire.



Solution

- ① Check the connection between MAIN PCB and STROBO FPCB.
- ② Check the connection between the internal STROBO WIRE HARNESS and STROBO FPCB.


Images for reference



4-14 NFC related problems

Problem	
NFC is not working.	
Solution	
See if the NFC CLIP on MAIN PCB is bent. Check the connection between the NFC CLIP and the antenna module. (You should remove the front cover to check the antenna module.)	
Images for reference	
	


4-15 BT/Wi-Fi problems

Problem	
BT/Wi-Fi is not working.	
Solution	
See if a RF antenna is properly assembled. Make sure it is not damaged.	
Images for reference	
	


5. PCB diagrams

5-1 MAIN PCB

TOP




BOTTOM




5-5 DRIVE FPCB

TOP




5-6 HOTSHOE FPCB

TOP




5-7 PROX FPCB

TOP




5-8 VGRIP FPCB

TOP




5-9 POWER KEY FPCB

TOP




BOTTOM




5-10 CIS HPCB

TOP




5-11 COMMAND FPCB

TOP



6. Block diagram

NX1 System Block Diagram
2014.02.25



7. Firmware update

7-1 Product Initialization



This section explains how you can initialize the product settings to factory-set defaults.

1. Save the 'nx_dev.adj' file in the top-level folder of your SD card and insert the card into your camera.



Fig. 7-1

2. Turn the camera on.



Fig. 7-2

3. Select 'Smart Auto' mode.



Fig. 7-3

4. Press the buttons in numerical order below.

① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ EV + OK(Hold down EV button and press OK.)



Fig.7-4

5. Select "2. SYSTEM PARAMETER" and press the OK button.



Fig. 7-5

6. Press the OK button to check the box "(1) FACTORY RESET".



Fig. 7-6

7. Turn the camera off.

8. Turn the camera on and check if the initialization is complete.

7-2 Body Firmware Update Using User Menu



- This section explains how you can update your camera with the latest version of firmware.
- Use AC adaptor or fully-charged battery for the update.
- Formatting will erase all saved data on the device. Please back up your data before updating.

1. Save the latest firmware file (nx1.bin) in the top-level folder of your SD card and insert the card into your camera.



Fig. 7-7

2. Turn the camera on.

3. Select "MENU →  → Device Information → Software Update".

4. Select "Body Firmware".



Fig. 7-8

5. Select 'Yes' to begin the update.



Fig. 7-9

6. It may take five minutes to update the firmware, and the camera will be rebooted twice during the update.
- Even if the screen turns off automatically during the update, do not turn the camera off or operate camera controls. Please wait until the update is completed.
 - When the update is completed, the camera will turn itself on and the monitor will display the update completed message.
 - If the message will not disappear, press the shutter button one time.



Fig. 7-10

7-3 Lens Firmware Update Using User Menu



- This section explains how you can firmware in latest version the equipped camera lens.
- Use AC adaptor or fully-charged battery for the update.
- Formatting will erase all saved data on the device. Please back up your data before updating.

1. Save the latest firmware file (lens.bin) in the top-level folder of your SD card and insert the card into your camera.



Fig. 7-11

2. Turn the camera on.

3. Select "MENU →  → Device Information → Software Update".

4. Select "Lens Firmware".



Fig. 7-12

5. Select 'Yes' to begin the update.



Fig. 7-13

6. It may take five minutes to update the firmware, and the camera will be rebooted twice during the update.
- Even if the screen turns off automatically during the update, do not turn the camera off or operate camera controls. Please wait until the update is completed.
 - When the update is completed, the camera will turn itself on and the monitor will display the update completed message.
 - If the message will not disappear, press the shutter button one time.



Fig. 7-14

7-4 Body Firmware Update Using DEV Mode



- This section explains how you can update your camera with the latest version of firmware.
- Use AC adaptor or fully-charged battery for the update.
- Formatting will erase all saved data on the device. Please back up your data before updating.

1. Save the 'nx_dev.adj, nx.bin' file in the top-level folder of your SD card and insert the card into your camera.



Fig. 7-15

2. Turn the camera on.



Fig. 7-16

3. Select 'Smart Auto' mode.



Fig. 7-17

4. Press the buttons in numerical order below.

① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ EV + OK (Hold down EV button and press OK.)



Fig.7-18

5. Select "1. FW UPDATE" and press the OK button.



Fig. 7-19

6. Select "(1) BODY F/W UPDATE" and press the OK button.



Fig. 7-20

7. The monitor will display firmware information. Press the OK button to begin the update.



Fig. 7-21

8. It may take five minutes to update the firmware, and the camera will be rebooted twice during the update.
- Even if the screen turns off automatically during the update, do not turn the camera off or operate camera controls. Please wait until the update is completed.
 - When the update is completed, the camera will turn itself on and the monitor will display the update completed message.
 - If the message will not disappear, press the shutter button one time.



Fig. 7-22

7-5 Lens Firmware Update Using DEV Mode



- This section explains how you can firmware in latest version the equipped camera lens.
- Use AC adaptor or fully-charged battery for the update.
- Formatting will erase all saved data on the device. Please back up your data before updating.

1. Save the 'nx_dev.adj, lens.bin' file in the top-level folder of your SD card and insert the card into your camera.



Fig. 7-23

2. Turn the camera on.



Fig. 7-24

3. Select 'Smart Auto' mode.



Fig. 7-25

4. Press the buttons in numerical order below.

① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ EV + OK (Hold down EV button and press OK.)



Fig.7-26

5. Select "1. FW UPDATE" and press the OK button.



Fig. 7-27

6. Select "(2) LENS F/W UPDATE" and press the OK button.



Fig. 7-28

7. The monitor will display firmware information. Press the OK button to begin the update.



Fig. 7-29

8. It may take five minutes to update the firmware, and the camera will be rebooted twice during the update.
- Even if the screen turns off automatically during the update, do not turn the camera off or operate camera controls. Please wait until the update is completed.
 - When the update is completed, the camera will turn itself on and the monitor will display the update completed message.
 - If the message will not disappear, press the shutter button one time.



Fig. 7-30

7-6 Main PCB Recovery



- This section explains how you can recover main PCB when the camera is not working due to unexpected problem during updating.
- **All data on the device will be saved. You do not need to manage the data to begin the recovery process.**

Preparation

- 1. Get a Micro SD card that is less than 1GB in size**
 - Cards with a capacity less than 1GB are recommended.
 - Some cards cannot be read. If the update cannot be processed, change the card and try it again.
- 2. Get tweezers.**
 - To make the TP spot electrically shorted.
- 3. Get recovery files: downloader.bin, nx1.bin**
 - File will differ depending on the model. Do not mix files.

1. Save recovery files(downloader.bin, nx1.bin) to memory card.
2. Remove all the Exterior screws → EYE PIECE → EVF COVER screws → EVF COVER → BACK COVER.
3. Solder the TP spot in a red circle of the picture below to make it electrically shorted.
 - Note that solder needs to be removed later.




Fig. 7-31

4. Attach the connector of back cover to the main PCB, and turn the power key on.
5. Insert the memory card from Step 1 and fully-charged battery into the camera.
6. LED lamp will be on in seconds. When the light is on, remove solder at the TP spot from Step 3.
7. Note that the monitor will automatically turns off and on during the task.
8. When all tasks is completed, a message will appear on the LCD monitor.
 - When all tasks is completed, a message will appear on the LCD monitor.
9. Attach the BACK COVER → EVF COVER → EVF COVER screws → EYE PIECE → Exterior screws.
10. Turn the camera on and check if the camera works.

8. Adjustment

8-1 Adjustment process guide



- After replacing the following parts, you need to adjust the following items.
- The table below provides information about the necessary adjustment process.

1. Please refer to the table information before beginning the adjustment process.

<Table. 8-1>

	MAIN PCB	CIS ASSY	SHUTTER	MOUNT	Required Equipment
Firmware update	O	O	O	O	Every Service Cases
CIS TILT ADJ	X	O	O	O	TILT Adjustment
CIS DOT DATA	O	O	X	X	Shutter Adjustment, CIS Dot Data File
SHUTTER ADJ	O	X	X	X	Shutter Adjustment
ISO ADJ	O	O	X	X	Light Box 3200K, Master Lens
AWB ADJ	O	O	X	X	
EFS ADJ	O	O	X	X	Light Box 3300K, LV16
VFPN & DEFECT ADJ	O	O	X	X	Mount Cap
COLOR SHADING	O	O	X	X	Light Box 5500K 16-50mm PWZ Lens
GYRO	O	X	X	X	Mount Cap
COUNTRY CODE	O	X	X	X	Change Script
MAC ADDR, SERIAL NO, BLUE TOOTH ADDR	O	X	X	X	Change Script
PAF	O	O	X	X	PAF Light Box, Controller
WiFi ON/OFF	X	X	X	X	Special Request Only

2. Required equipment specification

- Light Source Box 1 : LV-1450DC (3200K±50, Lv12)
- Light Source Box 2 : LSB-1/10 (5500K±100, Lv12)
- Light Source Box 3 : For Compact DSC (3300K, Lv. 16)
- Light Source Box 4 : PAF Light box & Controller
- Master Lens
- 30mm Lens
- 16-50mm PWZ Lens
- Tilt adjustment : RSM-5000(CSC center)
- Shutter adjustment : RFS-5910A (CSC center)



3200K



5500K



PAF Light Box & Controller

Fig. 8-1

8-2 CIS TILT Adjustment



Proceed CMOS Tilt adjustment after replacing CMOS ASSY.

<Adjustment method>

1. Set the CIS Tilt adjustment tools. (Kyoritsu (RSM-5000))
2. Once you press the Start button, Tilt adjustment will complete automatically.
3. After adjustment completion, Apply glue on three screws to fix the screw position as illustrated in Fig. 8-6.




Fig. 8-2

<Adjustment Result>

Adjust specification for Mount side and FLANGE BACK side : 25.55mm(-35mm/+15mm)
Adjust specification for CMOS sensor TILT side from center: -30um/+30um

8-3 CIS DOT DATA & SHUTTER ADJ



- Adjust the CIS data input and Shutter Speed.
- Preparation : PC, Program(NX1_ShutterTester_Ver5.1.exe)

<Adjustment method>

1. Extract dot data in C drive as NXCISTEMP_NX1.



Fig. 8-3

2. Open CIS DOT DATA folder.





Fig. 8-4

3. Copy "info.tgw" the file SD card.

4. Insert the card and connect the camera to PC.

5. Excute USBSet1.1.exe.



6. Cut USB ID, Clear channels and move to Channel 1.




Fig. 8-5

7. Execute NX1_ShutterTester_Ver5.1.exe Program.




Fig. 8-6

8. Select Option → Script File Open →“NX1 DOT DATA Shutter_141114.txt”.
 –Please check script file name & script command on window as below.




Fig. 8-7

9. Open “setup.ini” and change port number as shutter adjustment port

```

987
SCANNER1_COMPORT=1
SCANNER1_BAUD=115200
RFS1_COMPORT=4
RFS1_BAUD=9600
SCANNER2_COMPORT=8
SCANNER2_BAUD=115200
RFS2_COMPORT=3
RFS2_BAUD=115200
m_dShutterDataCompareValue=0.000000
PERIOD=4
PATH_C1SDAT=C:\NXC\SDAT_NX1
PATH_C1STEMP=C:\NXC\STEMP_NX1#
PATH_MODEL=VB2
    
```

Fig. 8-8

10. When turning on the camera, the process will proceed automatically.(DOT serial number input not required)

11. When it finishes normally, then there is a final message, “ADJ. Finished!” with green screen at camera
 And there is PASS message on the PC program.

8-4 Entering the CS Mode



Describes how to enter to CS Mode the Camera

1. Save the 'Adjustment, nx_cs.adj' file in the top-level folder of your SD card and insert the card into your camera.
 - The files inside the Adjustment folder as shown below.



Fig. 8-9

2. Turn the camera on.



Fig. 8-10

3. Select 'Smart Auto' mode.



Fig. 8-11

4. Press the buttons in numerical order below.

- ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ EV + OK (Hold down EV button and press OK.)



Fig. 8-12

5. Displayed the CS Mode as shown below.



Fig. 8-13

8-5 ISO Adjustment



- This section describes how to proceed the adjustment relating to the image quality.
- Preparation : LIGHT BOX (3200K, LV12), Master Lens(F#5.6)

<Adjustment method>

1. Install the master lens to the camera and then setting the camera to the Light source box of **3200K**.




Fig. 8-14

2. Insert the memory card containing the two adjustment files in below into the camera.

- Adjustment folder, nx_cs.adj files

3. To enter the CS MODE.

- Smart Auto mode → ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ OK (Hold down EV button and press OK.)

4. When you select the ISO, adjustment will automatically start.




Fig. 8-15

5. If the adjustment is completed, "ADJ. Finished!" message is displayed.

8-6 AWB Adjustment



- This section describes how to proceed the adjustment relating to the image quality.
- Preparation : LIGHT BOX (3200K, LV12), Master Lens(F#5.6)

<Adjustment method>

1. Install the master lens to the camera and then setting the camera to the Light source box of **3200K**.




Fig. 8-16

2. Insert the memory card containing the two adjustment files in below into the camera.

- Adjustment folder, nx_cs.adj files

3. To enter the CS MODE.

- Smart Auto mode → ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ OK(Hold down EV button and press OK.)

4. When you select the AWB, adjustment will automatically start.




Fig. 8-17

5. If the adjustment is completed, "ADJ. Finished!" message is displayed.

8-7 EFS (Electronic First Shutter) Adjustment



- Describes the how to adjustment associated for the Electron First Shutter properties.
- Preparation : Light Box (for compact DSC, 3300K, LV16 ±0.2)

<Adjustment method>

1. Install the master lens to the camera and then setting the camera to the Light source box of **3300K**.




Fig. 8-18

2. Insert the memory card containing the two adjustment files in below into the camera.
 - Adjustment folder, nx_cs.adj files

3. When you select the EFS from the CS MODE, adjustment will automatically start.




Fig. 8-19

4. If the adjustment is completed, "EFS SUCCESS!" message is displayed.

5. Check the adjustment result.

- With Shutter speed of 1/4000s, MF focus, take a picture of LV16 of Light box. Check if there's horizontal noise on the image.




Fig. 8-20

8-8 VFPN & DEFECT Adjustment



- This section describes how to correct the vertical noise & defect pixel according to CIS Temperature.
- Preparation : Mount Cap

<Adjustment method>

1. Install the mount cap to block the light.



Fig. 8-21

2. Insert the memory card containing the two adjustment files in below into the camera.

- Adjustment folder, nx_cs.adj files

3. To enter the CS MODE.

- Smart Auto mode → ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ OK (Hold down EV button and press OK.)

4. When you select the VFPN&DEFEC, adjustment will automatically start.




Fig. 8-22

5. If the adjustment is completed, "ADJ. Finished!" message is displayed.

8-9 COLOR SHADING Adjustment



- This section describes how to adjust the brightness and color deviation gap between center and around.
- Light Box 5500K, 16-50mm Lens

<Adjustment method>

1. Install the 16-50mm Lens to the camera and then setting the camera to the Light source box of **5500K**.




Fig. 8-23

2. Insert the memory card containing the two adjustment files in below into the camera.

- Adjustment folder, nx_cs.adj files

3. To enter the CS MODE.

- Smart Auto mode → ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ OK (Hold down EV button and press OK.)

4. When you select the COLOR_SHADING, adjustment will automatically start.




Fig. 8-24

5. If the adjustment is completed, "ADJ. Finished!" message is displayed.

8-10 COUNTRY CODE Setting (Wi-Fi)



It is required to reset up Wi-Fi setting for the specified country after replacing the Main PCB.

<Adjustment method>

1. Open Scripts file and input country code as country code table.

- Country code, see page 8-17.

```
// change country_code :
//   sys_param shipment_country set [country_code]
//   ex. sys_param shipment_country set 55
```

start

osd clear

///// change here /////

sys_param shipment_country set 55

////////////////////////////////////

Country Code
EX > sys_param shipment_country set 55
(korea code : 55)

Fig. 8-25

2. Insert the memory card containing the two adjustment files in below into the camera.

- Adjustment folder, nx_cs.adj files

3. To enter the CS MODE.

- Smart Auto mode → ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ OK (Hold down EV button and press OK.)

4. When you select the COUNTRY CODE, adjustment will automatically start.



Fig. 8-26

5. If the setting is completed, "ADJ. Finished!" message is displayed.

- If the camera is not set region after replacing the Main PCB or is purchased from overseas, there are some issues as below.

- 1) User does not use SNS service country-specific.
- 2) Do not support multiple languages for display and input when using Wi-Fi.
- 3) Wi-Fi telecommunication speed may be down.

8-11 SN & Mac ADDR Setting



It is required to input Serial number and Mac Address after replacing the Main PCB.

<Adjustment method>

1. Open Scripts file and input serial number and Mac address.

```
//-----
// 1 Input the Serial No. here.
// 제품라벨의 시리얼번호 15자리를 입력하세요.
line_process product_number set ABC123456789ABC
delay 500

//-----
// 2 Input the Network certification Number No. here
// Scan barcode on the S/N label, and input 12digit number.
// S/N 바코드를 Scan하여 12자리 네트웍인증번호를 입력하세요.
sys_serial set 012345678901
delay 500

//-----
// 3 Write the MAC address here.
// MAC address 12자리를 입력하세요.
wifi addr_set 2013e0f72e02
delay 500

//-----
// 4 Write the BLUETOOTH MAC address here.
// 블루투스 MAC address 12자리를 입력하세요.
bluetooth addr_set 2013e0f72e01
```

Fig. 8-27

2. Insert the memory card containing the two adjustment files in below into the camera.

- Adjustment folder, nx_cs.adj files

3. To enter the CS MODE.

- Smart Auto mode → ① Down → ② OK → ③ Up → ④ OK → ⑤ Right → ⑥ OK(Hold down EV button and press OK.)

4. When you select the SN & MAC ADDR, adjustment will automatically start.



Fig. 8-28

5. If the setting is completed, "ADJ. Finished!" message is displayed.

- When the original Mac address is gone and is changed to new one, please change SSID of NFC tag as new Mac address.

8-12 PAF Adjustment



■ Preparation : PAF Light Box, PC, PAF Light Controller, USB to Serial Cable.

<Adjustment method>

1. Connecting.

- 1) Copy "info.tgw" file to SD card and insert the SD card into the camera.
- 2) Please connect camera to PAF equipment and connect USB cable.




Fig. 8-29

2. Run PAF program (DITester.exe)

3. Read Script file

- Select LOG2 → Script Load → "NX1_CH2_PAF.txt" PAT Script → Close and open the program again.

4. If the script is loaded correctly, then the script name is on channel 2.





Fig. 8-30

5. USB to serial port setting.

- 1) After installing USB to serial cable driver, please connect cable to PC.
- 2) Check COM port number in device manger



- 3) Select "SETUP VIEW" and then Change COM port number in second channel and its speed as 9600.
- 4) Close and open the program again.





Fig. 8-31

6. Execute USBSet1.1.exe.



7. Cut USB ID, Clear channels and move to Channel 2.




Fig. 8-32

8. Execute PAF adjustment Program.
9. When turning on the camera, the process will proceed automatically.
10. When it finishes normally, then there is a final message, "PAF Adjust done" with green screen at camera And there is PASS message on the PC program.




Fig. 8-33

8-13 How to uninstall WI-FI Function

<Adjustment method>

1. Select WIFI ON from the CS MENU.




Fig. 8-34

2. When ON / OFF switch appears, the switch is select to OFF.
- If you select OFF, the Wi-Fi is turned off.

<Table. 8-2 Country code>


No.	Country	Cord	No.	Country	Cord	No.	Country	Cord
-	DEFAULT	- - -	47	IRAQ	047	94	SAUDI_ARABIA	094
1	AFGHANISTAN	001	48	ISRAEL	048	95	SEBJ	095
2	ALBANIA	002	49	ITALY	049	96	SECD	096
3	ALGERIA	003	50	IVORY COAST	050	97	SEGZ	097
4	ANGOLA	004	51	JAPAN	051	98	SENEGAL	098
5	ARGENTINA	005	52	JORDAN	052	99	Serbia	099
6	ARMENIA	006	53	KAZAKHSTAN	053	100	SESH	100
7	AUSTRALIA	007	54	KENYA	054	101	SESY	101
8	AUSTRIA	008	55	KOREA	055	102	SIEL(CALCUTTA)	102
9	AZERBAIJAN	009	56	Kyrgyzstan	056	103	SIEL(CHENNAI)	103
10	BANGLADESH	010	57	LAS_PALMAS	057	104	SIEL(DELHI)	104
11	BENIN	011	58	LATVIA	058	105	SIEL(MUMBAI)	105
12	BOSNIA ANDHERZEGOVINA	012	59	LEBANON	059	106	SIERRALEONE	106
13	BRAZIL	013	60	LIBERIA	060	107	SINGAPORE	107
14	BULGARIA	014	61	LIBYA	061	108	SINGER_SRI	108
15	BURKINA_FASO	015	62	MACEDONIA	062	109	SLOVAKIA	109
16	CAMEROON	016	63	MADAGASKAR	063	110	SLOVENIA	110
17	CANADA	017	64	MALAWI	064	111	SLOVENIA	111
18	CANARY	018	65	MALAYSIA	065	112	SOUTH_AFRICASPAIN	112
19	CAPEVERDE	019	66	MALI	066	113	SPAIN	113
20	CHILE	020	67	MAURITANIA	067	114	SRI_LANKA	114
21	CHINA	021	68	MAURITIUS	068	115	SRILANKA	115
22	COLOMBIA	022	69	MAYOTTE	069	116	SUDAN	116
23	CONGO	023	70	MEXICO	070	117	SWEDEN	117
24	CROATIA	024	71	MONGOLIA	071	118	SWITZERLAND	118
25	CYPRUS	025	72	MONTENEGRO	072	119	SYRIA	119
26	CZECHREPUBLIC	026	73	MOROCCO	073	120	TAIWAN	120
27	DENMARK	027	74	MOROCCO	074	121	TAJIKISTAN	121
28	DJIBOUTI	028	75	MYANMA	075	122	TANZANIA	122
29	EGYPT	029	76	NAMIBIA	076	123	THAILAND	123
30	ERITREA	030	77	NEPAL	077	124	TOGO	124
31	ETHIOPIA	031	78	NETHERLANDS	078	125	TUNISIA	125
32	FRANCE	032	79	NEW_ZEALAND	079	126	TURKEY	126
33	GABON	033	80	NIGERIA	080	127	TURKMENISTAN	127
34	GAMBIA	034	81	PAKISTAN	081	128	U.A.E	128
35	GEORGIA	035	82	PALESTINE	082	129	UGANDA	129
36	GERMANY	036	83	PALESTINE	083	130	UKRAINE	130
37	GHANA	037	84	PARAGUAY	084	131	UNITED_KINGDOM	131
38	Greece	038	85	PARAGUAY	085	132	UNITED_STATES	132
39	GSS_CO	039	86	PHILIPPINES	086	133	UNITEDARABEMIRATES	133
40	GUINEA	040	87	POLAND	087	134	URUGUAY	134
41	Guinea-Bissau	041	88	PORTUGAL	088	135	UZBEKISTAN	135
42	HONGKONG	042	89	REUNION	089	136	VIETNAM	136
43	HUNGARY	043	90	ROMANIA	090	137	YUGOSLAVIA	137
44	INDIA	044	91	RUSSIA	091	138	ZAMBIA	138
45	INDONESIA	045	92	RWANDA	092	139	ZIMBABWE	139
46	IRAN	046	93	SAMPLE	093			

9. Exploded view and parts list

9-1 BODY ASSEMBLY




- The Exploded view and parts list is displayed the only code of the BASIC MODEL.
- Later on the parts codes and derived models may have changed, please refer to the Exploded View on GSPN site.



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	AD97-24516A	ASSY-CASE REAR;NX1	1	X	
2	AD97-24527A	ASSY-COVER TOP;NX1	1	X	
3	AD97-24519A	ASSY-CASE FRONT;NX1	1	X	
4	AD97-24492A	ASSY CMOS;NX1	1	O	
5	AD97-24447A	ASSY-EYEPIECE;NX1	1	O	
6	AD97-24450A	ASSY COVER-EVF;NX1	1	O	
7	AD97-24451A	ASSY-EVF_KNOB;NX1	1	O	
8	AD67-02982A	RUBBER-VGRIP COVER	1	O	
9	AD63-07462A	CUSHION SHIELD FOAM-BACK	1	O	
10	AD61-06447A	HOLDER-TRIPOD;NX1,ZN,BLACK	1	O	
11	AD92-02268A	ASSY PBA MAIN-NX1 MAIN	1	O	


Loc. No	Parts No.	Description	Q ty	Available	Remark
12	6107-002736	SPRING-CS	3	0	
13	6001-002279	SCREW-MACHINE;CH,HEXA,M1.7,L4,ZPC(BLK)	3	0	
14	AD63-08065A	COVER-HOT SHOE;NX1,PC,BLACK	1	0	
15	AD66-01033A	DAMPER-SHUTTER;Allegro,HNBR,nat	2	0	
16	AD63-07526A	SHEET-FRAME BACK;NX300,ST850GFL	1	0	
17	AD97-23800A	ASSY-SHUTTER_COPAL	1	0	
18	6001-003186	SCREW-MACHINE;PH,+,M1.4,L5.0,ZPC(BLK)	13	0	
19	6001-002005	SCREW-MACHINE;PH,+,M1.4,L4,NI PLT(SIL)	7	0	
20	6001-001811	SCREW-MACHINE;PH,+,M1.4,L3,NI PLT,SWRCH1	2	0	
21	6003-001630	SCREW-TAPTYPE;PH,+,B,M1.4,L3.5,ZPC(BLK)	1	0	
22	6003-001658	SCREW-TAPTYPE;PH,B,M1.4,L6,ZPC(BLK)	1	0	
23	6009-001410	SCREW-SPECIAL;CH,+,M1.4,L4.7(2.5),ZPC(WHT)	2	0	
24	AD59-00248A	UNIT-BODY_PROX SENSOR	1	0	
25	AD62-00227A	PAD GAP-THERMAL;NX1,SI RUBBER,BLACK	1	0	

9-2 CMOS ASSEMBLY



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	AD92-02270A	ASSY PBA MAIN-NX1 CIS FPCB;NX1,NX1 CIS F	1	0	


9-3 REAR ASSEMBLY



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	6001-001811	SCREW-MACHINE;CH,+,M1.4,L3,NI PLT,SWRCH1	8	0	
2	6003-001630	SCREW-TAPTYPE;PH,+,B,M1.4,L3.5,ZPC(BLK),	3	0	
3	6107-001781	SPRING-CS;SUS304WPB,PI0.18,3.8,ID1.8,OD2	1	0	
4	AD02-00286A	TAPE SPONGE-GRIP REAR R;ACRYL FOAM,WL10,	1	0	
5	AD02-00321A	TAPE SPONGE-DECO MOUNT;NX1,ACRYL	1	0	
6	AD61-05314A	PLATE-MOUNT SPRING;NX200,STS	1	0	
7	AD61-06445A	HOLDER-MOUNT;NX1,AL,SILVER	1	0	


Loc. No	Parts No.	Description	Q ty	Available	Remark
8	AD61-06497A	PLATE-GROUND R;NX1,CU,SILVER	1	0	
9	AD61-06535A	MOUNT-LENS;NX1,STS316L	1	0	
10	AD63-07593A	SHEET-CONNECTOR;NX300,ST850GFL	3	0	
11	AD63-07861A	T/SHEET-CONDENSOR;NX30,TESA 4982	1	0	
12	AD63-08024A	GRIP-REAR R;NX1,TPU,BLACK,PC GF10%	1	0	
13	AD64-04167A	DECORATION-MOUNT;NX1,SUS,SILVER	1	0	
14	AD66-00945A	SHAFT-LENS DETECT;NX200,SUS303,SILVER	1	0	
15	AD67-02616A	CAP-MOUNT;NX300,PC,BLACK	1	0	
16	AD67-02990A	RUBBER-O-RING PLATE MOUNT;NX1,S	1	0	
17	AD92-02265A	ASSY PBA MAIN-NX1 VGRIP FPCB;NX1,NX1	1	0	
18	AD92-02276A	ASSY PBA MAIN-NX1 STROBO FPCB;NX1,NX1	1	0	
19	AD97-24440A	ASSY-CASE REAR SUB;NX1	1	0	
20	AD97-24442A	ASSY-HDMI;NX1	1	0	
21	AD97-24452A	ASSY-INNER MOUNT HOLDER;NX1	1	0	
22	AD97-24489A	ASSY COVER-BATTERY;NX1	1	0	
23	AD97-24548A	ASSY-CHAMBER_SUB;NX1	1	0	
24	AD97-24535A	ASSY-SD CARD_AS;NX1	1	0	
25	6001-003049	SCREW-MACHINE;PH,M1.7,L5,SILVER,	4	0	
26	6003-001859	SCREW-TAPTYPE;PH,+,M1.4,L5.0,ZPC(BLK)	1	0	
27	AD02-00335A	TAPE SPONGE-WP FRONT E;NX1	1	0	
28	AD02-00350A	CONDUCTIVE GASKET-NX1_GASKET_WIFI	1	0	
29	AD02-00368A	TAPE SPONGE-WP FRONT H;NX1	2	0	
30	AD63-05786A	SHEET-LEFT;HMX-H300,SED+TESA4972	2	0	
31	AD02-00282A	TAPE SPONGE-WP SD CARD A;NX1	1	0	

9-4 VGRIP FPCB ASSEMBLY



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	3001-002750	MICRO SPEAKER	1	0	


9-5 FRONT CASE ASSEMBLY



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	6001-001811	SCREW-MACHINE;CH,+,M1.4,L3,NI PLT	6	0	
2	6001-002742	SCREW-MACHINE;CH,M1.4,L2.5,ZPC(BLK)	4	0	
3	6003-001659	SCREW-TAPTYPE;PH,+,B,M1.4,L4,ZPC(BLK)	3	0	
4	AD02-00283A	TAPE SPONGE-WP SD CARD B;NX1	1	0	
5	AD02-00310A	TAPE SPONGE-WP FRONT A;	1	0	
6	AD02-00311A	TAPE SPONGE-WP FRONT B;	1	0	
7	AD02-00312A	TAPE SPONGE-WP FRONT C;	1	0	
8	AD02-00333A	TAPE SPONGE-BTOB VGRIP;NX1	1	0	
9	AD02-00336A	TAPE SPONGE-WP FRONT F;NX1	1	0	
10	AD02-00338A	TAPE DOUBLE FACE-FRONT GRIP;NX1	5	0	


Exploded view and parts list

Loc. No	Parts No.	Description	Q ty	Available	Remark
11	AD02-00345A	CONDUCTIVE GASKET-NX1_GASKET	1	0	
12	AD61-05966A	MAGNET-TILT A;NX300,Nd-Fe-B	2	0	
13	AD61-06429A	CASE-GRIP FRONT;NX1,TPU+PC,BLACK	1	0	
14	AD63-05161A	T/SHEET-SPEAKER RUBBER;PL150	2	0	
15	AD67-02956A	LENS-ACCESS;NX3000,PC,3020HFM/WH	1	0	
16	AD97-24432A	ASSY-WHEEL KEY_NX1;CSC,NX1	1	0	
17	AD97-24520A	ASSY COVER BACK-OLED TILT;NX1,BLACK	1	0	
18	AD97-24536A	ASSY-FRONT KEY;NX1	1	0	
19	AD97-24537A	ASSY-WIFI KEY;NX1	1	0	
20	AD97-24538A	ASSY-EVF KEY;NX1	1	0	
21	AD97-24539A	ASSY-PLATE EVF;NX1	1	0	
22	AD97-24540A	ASSY-CASE FRONT SUB;NX1	1	0	
23	AD63-07549A	SHEET-TILT FPCB;NX300,EFX01	1	0	
24	AD02-00368A	TAPE SPONGE-WP FRONT H;NX1	2	0	
25	AD02-00369A	TAPE SPONGE-WP FRONT I;NX1	2	0	

9-6 TOP CASE ASSEMBLY


Loc. No	Parts No.	Description	Q ty	Available	Remark
1	6001-002158	SCREW-MACHINE;PH,+,M1.4,L3.5,NI PLT	7	0	
2	6001-002641	SCREW-MACHINE;BH,+,M1.4,L3.5,NI PLT	3	0	
3	6003-001633	SCREW-TAPTYPE;CH,+,B,M1.4,L3,ZPC(BLK)	2	0	
4	6003-001658	SCREW-TAPTYPE;PH,B,M1.4,L6,ZPC(BLK)	1	0	
5	6003-001659	SCREW-TAPTYPE;PH,+,B,M1.4,L4,ZPC(BLK)	3	0	
6	AD02-00348A	CONDUCTIVE GASKET-NX1_SPONGE GASKET	1	0	
7	AD61-06233A	PLATE-LEVER POWER;NX30,STS	1	0	
8	AD97-24443A	ASSY-CASE TOP SUB;NX1	1	0	
9	AD97-24445A	ASSY-HOLDER BUTTON SHOT;NX1	1	0	
10	AD97-24446A	ASSY-HOLDER POP UP;NX1	1	0	
11	AD97-24453A	ASSY-LEVER_POWER;NX1	1	0	
12	AD97-24525A	ASSY-EVF;NX1	1	0	
13	AD97-24526A	ASSY-TOP LCD;NX1	1	0	
14	AD97-24542A	ASSY-RUBBER LIGHT KEY;NX1	1	0	
15	AD97-24543A	ASSY-TOP LCD SPONGE;NX1	1	0	
16	AD02-00305A	TAPE SPONGE-TOP REAR;	1	0	
17	AD02-00356A	TAPE SPONGE-STROBO N;NX1	2	0	
18	AD02-00359A	TAPE SPONGE-POWER LEVER WASHER;NX1	1	0	
19	AD02-00366A	TAPE SPONGE-STROBO S;NX1	1	0	
20	AD02-00369A	TAPE SPONGE-WP FRONT I;NX1	2	0	

9-7 TOP SUB CASE ASSEMBLY



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	AD61-06005B	PLATE-SPRING SHOE_WH	1	0	
2	AD97-24524A	ASSY-TOP LEFT	1	X	
3	AD67-02581A	RUBBER-MIC	1	0	
4	3003-001198	MIC-CONDENSER	1	0	

9-8 TOP LCD ASSEMBLY



Loc. No	Parts No.	Description	Q ty	Available	Remark
1	AD67-02581A	RUBBER-MIC	1	0	
2	3003-001198	MIC-CONDENSER	1	0	



Area	Web Site
Europe, MENA, CIS, Africa	https://gspn1.samsungcsportal.com
E.Asia, W.Asia, China, Japan	https://gspn2.samsungcsportal.com
N.America, S.America	https://gspn3.samsungcsportal.com

This Service Manual is a property of Samsung Electronics Co.,Ltd.
Any unauthorized use of Manual can be punished under
applicable International and/or domestic law.

© 2014 SAMSUNG Electronics Co.,Ltd
All rights reserved.
Printed in Korea
Code No: NX1